



Jumru

Jumru[®]



Table of Contents


Brother 2

Brother**Brother Catcher**Model: 30.043

SSSS60-292 = Dürkopp 0367050070

**Brother Catcher**Model: 30.033

S32474-001

**Brother Catcher**Model: 30.040

S07526-001

**Brother Catcher**Model: 28.758


159365-001



Brother Knife

Model: 30.044

SSSS60-302 = Dürkopp 0367350050



Brother Knife

S35480-101



Brother Knife

Model: 30.063

S35437-101



Brother Knife

Model: 30.034

S32477-001



Brother Knife

Model: 30.051


S27634-001 = Pfaff 91-119202-05



Brother Knife

Model: 30.071


S20899-001



Brother Knife

Model: 30.068


S20898-001



Brother Knife

Model: 30.066

S20897-001



Brother knife

Model: 30.065

S20896-001



Brother Knife

Model: 30.075

S20583-001



Brother Knife

Model: 30.072

S20582-001



Brother Knife

Model: 30.067

S20579-001



Brother Knife

Model: 30.037

S16248-101



Brother Knife

Model: 30.009

S10605-201



Brother Knife

Model: 30.035

S10605-001



Brother Knife

Model: 30.017

S10210-001



Brother Knife

Model: 30.016


S10205-001



Brother Knife

Model: 28.752


S09101-001



Brother Knife

Model: 28.746

S09094-001 (CT)



Brother Knife

Model: 28.751

S09093-001 (CT)



Brother Knife

Model: 28.750


S09080-001 (CT)



Brother Knife

Model: 28.749

S09075-001



Brother Knife

Model: 30.015

S08934-001



Brother Knife

Model: 30.042


S07527-001



Brother Knife

Model: 30.047


S03629-001



Brother Knife

Model: 30.046


S03627-001



Brother Knife

Model: 28.755

S02645-001



Brother Knife

Model: 28.756


S02637-001



Brother Knife

Model: 30.018

S02375-001



Brother Knife

Model: 30.019


S02374-001



Brother Knife

Model: 30.025

S00713-001



Brother Knife

Model: 30.024

S00706-201



Brother Knife

Model: 30.073

CTS20582-001 = 202893 Pegasus



Brother Knife

Model: 27.867

CT144077-001



Brother Knife

Model: 27.864

CT140567-001



Brother Knife

Model: 28.368

CT112436-001

Brother KnifeModel: 28.376

71-90 9/16 HSS

Brother KnifeModel: 28.381

71-90 7/8 HSS

Brother KnifeModel: 28.374

71-90 7/16 HSS

Brother KnifeModel: 28.377

71-90 5/8 HSS

Brother KnifeModel: 28.372

71-90 5/16 HSS

Brother knifeModel: 28.373

71-90 3/8 HSS

Brother KnifeModel: 28.379

71-90 3/4 HSS

Brother KnifeModel: 28.382

71-90 15/16 HSS

Brother KnifeModel: 28.380

71-90 13/16 HSS

Brother KnifeModel: 28.378

71-90 11/16 HSS

Brother KnifeModel: 28.370

71-90 1/8 HSS

Brother KnifeModel: 28.371

71-90 1/4 HSS

Brother KnifeModel: 28.375**Brother Knife**Model: 28.389

71-90 1 HSS

Brother KnifeModel: 27.018

71 9/16 HSS

Brother KnifeModel: 27.023

71 7/8 HSS

Brother KnifeModel: 27.016

71 7/16 HSS

Brother KnifeModel: 27.019

71 5/8 HSS

Brother KnifeModel: 27.014

71 5/16 HSS

Brother KnifeModel: 27.015

71 3/8 HSS

Brother KnifeModel: 27.021

71 3/4 HSS

Brother KnifeModel: 27.024

71 15/16 HSS

Brother KnifeModel: 27.022

71 13/16 HSS

Brother KnifeModel: 27.020

71 11/16 HSS

Brother KnifeModel: 27.012

71 1/8 HSS

Brother KnifeModel: 27.013

71 1/4 HSS

Brother KnifeModel: 27.017

71 1/2 HSS

Brother KnifeModel: 27.030

71 1 3/8 HSS

Brother KnifeModel: 27.028

71 1 3/16 HSS

Brother KnifeModel: 27.027

71 1 1/8 HSS

Brother KnifeModel: 27.029

71 1 1/4 HSS

Brother KnifeModel: 27.031


71 1 1/2 HSS

Brother KnifeModel: 27.026

71 1 1/16 HSS

Brother KnifeModel: 27.025


71 1 HSS

**Brother Knife**Model: 30.030

159915-001

**Brother Knife**Model: 30.031


159799-001

**Brother Knife**Model: 30.032

159541-001

**Brother Knife**Model: 28.757


159540-001

**Brother Knife**Model: 30.026


154575-001

**Brother Knife**Model: 30.027

154568-001

**Brother Knife**Model: 30.022

154176-001



Brother Knife

Model: 30.036

153019-001 =Eagle 21-4001



Brother Knife

Model: 30.021

152905-001

152905-001



Brother Knife

Model: 27.865

148815-001 (CT)



Brother Knife

Model: 28.737

148198-001



Brother Knife

Model: 27.004

144077-001



Brother Knife

Model: 27.003

144074-001 (CT)



Brother Knife

Model: 30.070


144074-200 144074-300



Brother Knife

Model: 30.069


144074-001



Brother Knife

Model: 27.032


142061-001



Brother Knife

Model: 27.033


142058-001



Brother Knife

Model: 30.039


141541-001



Brother Knife

Model: 30.038


141 543-001



Brother Knife

Model: 27.009

140567-001



Brother Knife

Model: 27.011

140242-001 (CT)



Brother Knife

Model: 27.001

118527-001



Brother Knife

Model: 27.006

112436-001 155193-001



Brother Knife

Model: 27.005

112376-001



Brother Knife Ceramic

Model: 30.074

S20582-001BAK



Brother Knife Ceramic

Model: 30.064


112436-001BAK




Brother Knife

Model: 30.023


152906-001

**Brother Knife**Model: 30.020


152901-001

**Brother Looper**Model: 30.050

SY0069086

**Brother Looper**Model: 30.049


SY0069085

**Brother Looper**Model: 30.048

SY0069084

Brother LooperModel: 30.096

S40394-001



Brother Looper

Model: 30.095


S40393-001



Brother Looper

Model: 30.094

S40392-001



Brother Looper

Model: 30.093


S40391-001



Brother Looper

Model: 30.092

S40390-001



Brother Looper

Model: 30.091


S40389-001



Brother Looper

Model: 30.054


S40377-001



Brother Looper

Model: 30.056

S40376-001



Brother Looper

Model: 30.055

S40375-001



Brother Looper

Model: 30.055


S35411-001



Brother Looper

Model: 30.056


S35410-001



Brother Looper

Model: 30.077

S20653-001



Brother Looper

Model: 30.076

S20626-001



Brother Looper

Model: 30.086

S20442-001



Brother Looper

Model: 30.085

S20440-001



Brother Looper

Model: 30.079

S20438-001



Brother Looper

Model: 30.084

S20436-001



Brother Looper

Model: 30.083


S20434-001



Brother Looper

Model: 30.082

S20430-001



Brother Looper

Model: 30.089

S20429-001



Brother Looper

Model: 30.078


S20428-001



Brother Looper

Model: 30.081

S20424-001



Brother Looper

Model: 30.088


S20423-001



Brother Looper

Model: 30.080

S20422-001



Brother Looper


Model: 30.087

S20421-001

Brother Looper

Model: 28.754


S12865-001



Brother Looper

Model: 28.753

S12842-001



Brother Looper


Model: 28.747

S08913-001

Brother Looper

Model: 30.045

S03536-001



Brother Looper

Model: 27.040


S01248-001 144049-001



Brother Looper

Model: 28.740

159686-001



Brother Looper

Model: 28.745

159434-001(F) S01249-001



Brother Looper

Model: 28.744

155243-001(H)



Brother Looper

Model: 28.743

155242-001(S)



Brother Looper

Model: 28.742

155241-001



Brother Looper

Model: 28.741

155240-001



Brother Looper

Model: 30.054


148871-001



Brother Looper

Model: 30.053


148870-001



Brother Looper

Model: 30.052


148869-001



Brother Looper

Model: 28.870


147937-001 146962-001



Brother Looper

Model: 28.369

147936-001 146792-001



Brother Looper

Model: 28.738


147935-001 146613-001



Brother Looper

Model: 27.869


147934-001 146042-001, 146612-001



Brother Looper

Model: 27.041


146635-001



Brother Looper

Model: 28.739


144042-001



Brother Looper

Model: 27.039

143734-001



Brother Looper

Model: 28.762


127815-001 KI.127



Brother Looper

Model: 28.761

127814-001 KI.127



Brother Looper

Model: 28.763

127260-001 KI.522



Brother Looper

Model: 28.759


115069-001



Brother Looper

Model: 27.037

110737-001



Brother Looper

Model: 27.036

110736-001



Brother Looper

Model: 27.034

110121-001



Brother Spreader

Model: 30.058

S35413-101

Brother Spreader

Model: 30.057

S35412-101


Brother Steel

Model: 30.061

S35479-001 50 mm

Brother SteelModel: 30.060

S35093-001 38 mm

**Brother Steel**Model: 30.059

S35092-001 20 mm

