



*Jumru*

**Jumru**<sup>®</sup>



---

# Índice

Singer..... 2

## Singer

### Singer Aço

Modelo: 30.642

548771 1 5/8"

### Singer Aço

Modelo: 30.641

548770 1 1/2"

### Singer Aço

Modelo: 30.640

548769 1 3/8"

### Singer Aço

Modelo: 30.639

548768 1 1/4"

### Singer Aço

Modelo: 30.638

548767 1 1/8"

Singer Aço

Modelo: 30.637

548766 1"

Singer Aço

Modelo: 30.636

548765 7/8"

Singer Aço

Modelo: 30.635

548764 3/4"

Singer Aço

Modelo: 30.634

548763 5/8"



Singer Aço


Modelo: 30.633

548762 1/2"

Singer Guia

Modelo: 30.602

268310



Singer Lâmina

Modelo: 27.503

GU 3606, Peschke Nr. 18



Singer Lâmina

Modelo: 27.502

GU 3605, Peschke Nr. 19



Singer Lâmina

Modelo: 28.895

CT82264

Singer Lâmina

Modelo: 28.603

CT42309

Singer Lâmina

Modelo: 28.602

CT42305



Singer Lâmina

Modelo: 27.496

CT270619



Singer Lâmina

Modelo: 27.495

CT270616



Singer Lâmina

Modelo: 28.894

CT164556



Singer Lâmina

Modelo: 28.892


CT164550



Singer Lâmina

Modelo: 28.891


CT164308



Singer Lámina

Modelo: 28.893

CT164026



Singer Lámina

Modelo: 27.489

8061 A-3.1



Singer Lámina

Modelo: 27.501

785780-001

Singer Lámina

Modelo: 27.425a

71-90 9/16 HSS

Singer Lámina

Modelo: 27.427a

71-90 7/8 HSS

**Singer Lâmina**Modelo: 27.423a

71-90 7/16 HSS

**Singer Lâmina**Modelo: 27.426a

71-90 5/8 HSS

**Singer Lâmina**Modelo: 27.421a

71-90 5/16 HSS

**Singer Lâmina**Modelo: 28.373

71-90 3/8 HSS

**Singer Lâmina**Modelo: 27.429a

71-90 3/4 HSS

**Singer Lâmina**Modelo: 27.431a

71-90 15/16 HSS



**Singer Lâmina**Modelo: 27.430a

71-90 13/16 HSS

**Singer Lâmina**Modelo: 27.428a

71-90 11/16 HSS

**Singer Lâmina**Modelo: 28.370

71-90 1/8 HSS

**Singer Lâmina**Modelo: 28.371

71-90 1/4 HSS

**Singer Lâmina**Modelo: 27.424a

71-90 1/2 HSS

**Singer Lâmina**Modelo: 30.647

71-90 1 1/8 HSS

**Singer Lâmina**Modelo: 30.646

71-90 1 1/4 HSS

**Singer Lâmina**Modelo: 27.432a

71-90 1 HSS

**Singer Lâmina**Modelo: 27.425

71 9/16 HSS

**Singer Lâmina**Modelo: 27.427

71 7/18 HSS

**Singer Lâmina**Modelo: 27.423

71 7/16 HSS

**Singer Lâmina**Modelo: 27.426

71 5/8 HSS

**Singer Lâmina**Modelo: 27.421

71 5/16 HSS

**Singer Lâmina**Modelo: 27.422

71 3/8 HSS

**Singer Lâmina**Modelo: 27.429

71 3/4 HSS

**Singer Lâmina**Modelo: 27.431

71 15/16 HSS

**Singer Lâmina**Modelo: 27.430**Singer Lâmina**Modelo: 27.428

71 11/16 HSS

**Singer Lâmina**

 Modelo: 27.419

71 1/8 HSS

**Singer Lâmina**

 Modelo: 27.420

71 1/4 HSS

**Singer Lâmina**

 Modelo: 27.424

71 1/2 HSS

**Singer Lâmina**

 Modelo: 27.437

71 1 3/8 HSS

**Singer Lâmina**


 Modelo: 27.435


71 1 3/16 HSS

**Singer Lâmina**

 Modelo: 27.434


71 1 1/8 HSS




**Singer Lâmina**


 Modelo: 27.436

71 1 1/4 HSS


**Singer Lâmina**


 Modelo: 27.438

71 1 1/2 HSS


**Singer Lâmina**


 Modelo: 27.433

71 1 1/16 HSS


**Singer Lâmina**

 Modelo: 27.432

71 1 HSS


**Singer Lâmina**

 Modelo: 30.645

548936



Singer Lámina

Modelo: 30.644


548935



Singer Lámina

Modelo: 30.643

548886



Singer Lámina

Modelo: 30.632

544599



Singer Lámina

Modelo: 30.631

414030



Singer Lámina

Modelo: 30.630

414029



Singer Lámina


Modelo: 28.918

412585 (CT)


**Singer Lámina**

 Modelo: 27.390

40048      Kl. 71-30


**Singer Lámina**

 Modelo: 27.493

40035      271926


**Singer Lámina**

 Modelo: 27.417

39867      Kl. 71-48/71-112


**Singer Lámina**

 Modelo: 27.391

39609      Kl. 71-30


**Singer Lámina**

 Modelo: 30.620

377560      G60540114P700



Singer Lâmina

Modelo: 30.619

377559 G6050113C500



Singer Lâmina

Modelo: 30.618

377465



Singer Lâmina

Modelo: 30.617


377462 6031314C500



Singer Lâmina

Modelo: 30.616

377443 6031218P700




Singer Lâmina

Modelo: 30.615

344559






Singer Lâmina

Modelo: 28.583

249191-3.1



Singer Lâmina

Modelo: 27.490


249191 HSS



Singer Lâmina

Modelo: 27.482

241574 HSS



Singer Lâmina

Modelo: 28.582


238508 HSS



Singer Lâmina

Modelo: 27.459

164813 (CT)



Singer Lámina

Modelo: 27.450


164809 (CT)



Singer Lámina

Modelo: 28.889


147211, 276489 (CT)



Singer Lámina

Modelo: 28.005


107519= 2119685 Dürkopp



Singer Lámina

Modelo: 30.606

540760



Singer Lámina

Modelo: 30.605

540741



Singer Lâmina

Modelo: 28.917


410295



Singer Lâmina

Modelo: 30.604

373539



Singer Lâmina

Modelo: 30.603

373537



Singer Lâmina

Modelo: 29.072


270619



Singer Lâmina

Modelo: 29.071

270616



Singer Lámina

Modelo: 28.606

239715



Singer Lámina

Modelo: 27.500

239372



Singer Lámina

Modelo: 27.996


239367



Singer Lámina

Modelo: 30.601


238548



Singer Lámina

Modelo: 27.487


238546



Singer Lâmina

Modelo: 27.486


238543



Singer Lâmina

Modelo: 27.485

238508



Singer Lâmina

Modelo: 27.479

233934

Singer Lâmina

Modelo: 27.457

164728



Singer Lâmina

Modelo: 27.305


164556

**Singer Lâmina**Modelo: 27.456

164552

**Singer Lâmina**Modelo: 27.384

164550

**Singer Lâmina**Modelo: 27.383


164308

**Singer Lâmina**Modelo: 27.387

164233

**Singer Lâmina**Modelo: 27.386

164037



Singer Lâmina

Modelo: 27.382

164026



Singer Lâmina

Modelo: 27.415


107797



Singer Lâmina

Modelo: 30.600

82264



Singer Lâmina

Modelo: 27.498

55459



Singer Lâmina

Modelo: 27.499


55458

**Singer Lámina**Modelo: 27.381


42309

**Singer Lámina**Modelo: 27.380

42305

**Singer Looper**Modelo: 30.648

UL605294


**Singer Looper**Modelo: 30.629

377740 UL603881 UL600881

**Singer Looper**Modelo: 30.628

377691 GUL605150






Singer Looper

Modelo: 30.627


377641 LL604884 LL600884



Singer Looper

Modelo: 30.626


377640 LL604885



Singer Looper

Modelo: 30.625


377639 GUL604152



Singer Looper

Modelo: 30.624


377638 UL604883 UL600883




Singer Looper

Modelo: 30.623

377602 LL603884

**Singer Looper**Modelo: 30.622

377601 UL603886 UL600886

**Singer Looper**Modelo: 30.621

377600 UL603880 UL600880

**Singer Looper**Modelo: 30.614

32824

**Singer Looper**Modelo: 30.613

32823

**Singer Looper**Modelo: 30.612


32821



Singer Looper

Modelo: 30.611


32820



Singer Looper

Modelo: 29.070

268382 281208



Singer Looper

Modelo: 30.610


548232



Singer Looper

Modelo: 30.609


548231



Singer Looper

Modelo: 30.608


548207



Singer Looper

Modelo: 30.607


548205



Singer Looper

Modelo: 28.916

412553



Singer Looper

Modelo: 28.915


410452



Singer Looper

Modelo: 28.914


410434



Singer Looper

Modelo: 28.913

410262



Singer Looper

Modelo: 27.474

268380

Singer Looper

Modelo: 27.406

175547



Singer Looper

Modelo: 27.405

175085



Singer Looper

Modelo: 27.401

164619



Singer Looper

Modelo: 27.400

164375



Singer Looper

Modelo: 27.399


164252



Singer Looper

Modelo: 27.397


164045



Singer Looper

Modelo: 27.506

42239



Singer Looper

Modelo: 27.396

42220



Singer Looper

Modelo: 27.997

42072


**Singer Placa**

 Modelo: 27.462

5730 3/32      142032, 52131


**Singer Placa**


 Modelo: 27.464

5730 3/16


**Singer Placa**

 Modelo: 27.463

"5730 1/8"


**Singer Placa**

 Modelo: 27.409

39608      Kl. 71-30

